

Instructions:

This product can be delicate. When preparing this product for use, please support the eyelet whilst inserting the suckers (this works best using a screwing motion) as it is possible to push the eyelets out of the material.

To fasten screens, push the suckers onto the glass. If the suckers are not sticking well you may need to clean the glass (even glass that looks clean can sometimes have a film of dirt). Moistening the sucker can also help.

The suckers can sometimes become misshapen which can cause the suckers not to stick. This can easily be rectified by putting the suckers in warm water (no hotter than hand temperature hot) before sticking to some glass to regain their shape.

To remove the screens, pull on the suckers one by one, **never removing them by pulling the material**. If the windows have a darkened tinting film on them then the suction may lift this film so extra care needs to be taken. The suckers can also easily be removed by lifting the edge of the material and removing the sucker by gently touching or pushing the edge of the sucker cup to break the seal.

N.B: Please note that whilst every attempt is made to ensure that these instructions are accurate and clear, we cannot be held responsible for the misinterpretation of these instructions or for any subsequent accident or damage caused through mis-fitted parts.